# **EBS PRODUCTS**

WWW.ebsproducts.com

# **OPERATIONS MANUAL**



EDS-1 Dip Stick Fluid Exchange Equipment #1000-0075

<u>1-1-16</u>

## TABLE OF CONTENTS

I. SAFETY INFORMATION2	
1.01 IMPORTANT SAFETY NOTICE2	
1.02 IMPORTANT SAFETY INSTRUCTIONS2	
3.02 IDENTIFYING THE SYSTEM FLUID REQUIREMENTS	6
EBS Products	
Wastminster CA 92683	

Phone: 877-955-0515

Fax: 714-896-6711

E-mail: <a href="mailto:sales@ebsproducts.com">sales@ebsproducts.com</a>

# I. SAFETY INFORMATION

### 1.01 IMPORTANT SAFETY NOTICE

For your safety, read this manual thoroughly before operating your EBS Dip Stick Fluid Exchange Equipment. Always refer to and follow the safety messages and applicable service procedures provided by the manufacturer of the vehicle being serviced. Only properly trained professional automotive technicians should perform the service. *Improper use and operation of this product can result in injury*.

Safety Symbols



Risk of Fire



**Mandatory Eye Protection** 



Risk of Entanglement



**Mandatory Protective Gloves** 



**Dangerous Fumes** 



**Mandatory Protective Clothing** 

### 1.02 IMPORTANT SAFETY INSTRUCTIONS















Insure both ambient and electro mechanical ventilation of work area.

When using chemicals always refer to the MSDS sheets and local laws for proper emergency medical treatment, cleanup, handling, and storage requirements.

Wear safety glasses (user and bystanders), chemical resistant gloves, and protective clothing when servicing a vehicle with the EBS Dip Stick Fluid Exchange Equipment.

Keep yourself, clothing, adapters and service hoses clear of moving parts. Avoid exposure to flames, sparks, hot engine parts, and other ignition sources Care should be taken to arrange the power cord and service hoses so that they will not be tripped over or pulled.

#### EBSProducts.com



Ph: 877-955-0515 F: 714-896-6711

-----

### EDS-1 #1000-0075 Dip Stick Fluid Exchange Equipment Specifications

- ⇒ Heavy duty HDPE cabinet with a built in handle, locking front swivel wheels and large 8" rear wheels
- ⇒ Both 110vac fused power converted to 12vdc operation or 12vdc battery power available
- ⇒ Heavy Duty 110vac 22 ft. power cord with holder
- ⇒ 12ft. Heavy Duty 12vdc battery cable attached to cabinet
- ⇒ Easy to use electric switch control panel
- ⇒ Two 2 gallon new fluid tanks, front visible, level marked and top filled for your choice of oil, transmission fluids, etc. No brake or coolant fluids
- $\Rightarrow$  1.0 GPM rated separate fill pumps for each new fluid tank 6.5 ft. braided service hoses
- ⇒ Two- separate 2.5 gallon marked waste tanks service tank in top receptacle – spare in the rear of the cabinet
- ⇒ Heavy duty ½ GPM vacuum pump 5.5ft. braided service hose
- ⇒ Dual service valve control of fill and vacuum for active servicing
- ⇒ 6 foot braided fill and vacuum hoses
- $\Rightarrow$  4 foot each .180" id and .242" id dipstick service hoses with quick connects
- ⇒ Hose drain reservoir for dipstick hoses

#### **Machine Dimensions:**

Height	48 ½ inches
Depth	27 inches
Width	19 inches
Machine	65 lbs.
Weight	
Shipping	105 lbs.
Weight	



1-1-16



# III. OPERATING PROCEDURES

# Call 877-955-0515 for any operation, service or maintenance questions

## 3.01 CONTROL PANEL OVERVIEW



Figure 1

## **KEYS NAME/FUNCTION DETAILS**

VAC Turns vacuum on for vacuuming.

**NEW 1 FILL** Pumps New Fluid from the New 1 Fluid Tank

**NEW 2 FILL** Pumps New Fluid from the New 2 Fluid Tank

#### 3.02 IDENTIFYING THE SYSTEM FLUID REQUIREMENTS

Identify the OEM fluid specification of the vehicle to be serviced before performing any set up or servicing procedure on vehicle. Follow the vehicle manufacturer's recommendation for fluid type.

### 3. Vehicle Preparation for Dip Stick Fluid Exchange

- 1. Insure vehicle is safely parked and engine is OFF.
- 2. Repair any leaks or malfunction prior to fluid service.
- 3. Refer to manufacturer's maintenance manual for compliance with manufacturer's precautions or recommendations prior to exchanging fluid.
- 4. Wear appropriate protective clothing and goggles.

### 3.04 Equipment Preparation

- 1. Place equipment in a safe area at the front of the vehicle perpendicular to the vehicle's direction and lock equipment wheels. Locate and confirm dip stick for fluid being serviced.
- 2. Turn all switches to the "OFF" position left side of switch will be unlighted.
- 3. Plug machine into a grounded 110 VAC electrical outlet. or attach battery cables to vehicle battery. Select power source see Figure 2
- 4. Turn equipment on. If 110vac powered, verify that the light on the main "Power" switch is illuminated and no equipment pumps turn on. If 12vdc powered turn VAC switch ON momentarily to verify 12vdc power.







Figure 2 Figure 3 Figure 4

3.05 <u>Empty WASTE TANK</u> – Start with empty Waste Tank properly connected on top of equipment – See Figure 3

3.06 <u>Fill NEW FLUID TANK</u> – see Figure 4 – Fill NEW 1 Tank or NEW 2 Tank with the proper fluid for the service to be performed.

### 4.00 Vehicle Dip Stick Fluid Servicing

- 1. Remove vehicle dip stick always check for fluid condition and contaminants.
- 2. Connect Vacuum and Fill Service Hoses to Service Manifold See Figure 5 and largest Dip Stick Service Hose to end of Service Manifold See Figure 6.







Figure 5 Figure 6 Figure 7

- 3. Turn VAC Switch ON and monitor old fluid entering Waste Tank on top of equipment See Figure 7
- 4. When waste fluid has been removed, turn VAC Switch OFF observe waste fluid volume removed
- 5. At this time the pan can be dropped transmission service or the oil filter removed and replaced oil service.
- 6. Once completed, turn NEW 1 or 2 FILL Switch ON and refill with the volume removed in Step 4 above.
- 7. Turn all switches OFF.
- 8. It is recommended that the waste tank be emptied at the end of each service so proper monitoring of fluid removed from the vehicle can be replaced.

For any service or operation issues please call EBS Technical Support at 877-955-0515

PART# DESCRIPTION **CASTER SWIVEL, SILVER SIDE BRAKE** 1220-0026 1220-0022 **REAR WHEEL AXLE** 3000-0420 **WASTE TANK 2.5 GALLONS** NYLON DIP STK HOSES - 4FT - .180 AND .242ID'S 3000-0096 3000-0020 **GEAR OIL FILL PUMP GEAR OIL VACUUM PUMP** 3000-0050 **FILTER** 3000-0058 **HIGH FLOW GUN 1/4" FNPT** 3000-0100 3000-0015 **NEW 1 GALLON TANKS** 1520-0000 **ELECTRIC BOX** 3000-0320 **POWER SUPPLY 150 W** 1520-0020 **MAIN POWER SWITCH** MINIATURE VALVE 3/8" FNPT X 3/8" FNPT 3000-0060 1520-0010 **POWER CORD CONNECTOR** 1220-1023 **CAPS FOR 640Z BOTTLE** 1520-0040 **POWER CORD** 3000-0410 **FACE PLATE SWITCHES** 3000-0400 **TOUCH PAD** 

# LIMITED TWO (2) YEAR WARRANTY

EBS warrants only to the original Purchaser that under normal use, care and service, the Dip Stick Fluid Service Equipment shall be free from defects in material and workmanship for two year from the date of original purchase. External hoses, remote control modules, adapters and all other attachments, supplies and consumables are warranted for 90 calendar days from the date of original invoice. Filter elements are not warranted.

PURCHASER'S TECHNICIAN MUST HAVE TELEPHONE COMMUNICATIONS WITH EBS TECHNICAL SUPPORT TO DIAGNOSE THE PROBLEM AND DETERMINE IF THE PROBLEM IS A WARRANTY ISSUE BEFORE ANY REPAIRS OR REPLACEMENT CAN BE MADE.

This warranty does not cover (and separate charges for parts, labor and related expenses shall apply to) any damage to, malfunctioning, inoperability or improper operation of the equipment caused by, resulting from or attributable to (A) abuse, misuse or tampering-the use of the equipment with non-approved fluids is misuse; (B) alteration, modification or adjustment of the equipment, improper or negligent use, application, operation, care, cleaning, storage or handling; attachments, supplies or consumables not manufactured or supplied by Seller.